

Maintenance details for L956FH

Maintenance site	Maintain contents	Maintenance cycle (h)									Specification and code
		100	250	500	750	1000	1250	1500	1750	2000	
Engine	Engine oil	●	*	*	*	*	*	*	*	*	CD 15W/40
	Oil filter element	●	*	*	*	*	*	*	*	*	4110003316001
Fuel system	Oil - water separator filter element			*		*		*		*	4110002989004
	Primary fuel filter element		*	*	*	*	*	*	*	*	4110003450001
Air cleaner	Air cleaner element			*		*		*		*	4110001755023
Cooling system	Coolant									*	—35#
Transmission system	Hydraulic transmission oil			●		*				*	Hydraulic transmission oil 6#
	Transmission respirator filter element					*				*	4110001544001
	Transmission oil filter element			●		*				*	4110003167001
	Drive axle gear oil			●		*				*	GL-5 85W/90
Hydraulic system	Hydraulic oil									*	L-HM46#
	Pilot filter element					*				*	4120001954001
	Hydraulic tank respirator filter element									*	4120001088
	Oil return filter element					*				*	4120003296
Braking System	Braking respirator					*				*	4120008464
	Braking fluid			*		*		*		*	DOT4